

Welke Instant Pot Multicooker past bij jou?



Instant Pot®



Instant Pot serie →	Duo	Duo Plus	Duo Nova	Duo Evo Plus	Duo Crisp	Pro	Pro Crisp	Pro Plus Wi-Fi	Duo Crisp Ultimate
Beschikbaar in de maten:	3L / 5,7L / 7,6L	5,7L / 7,6L	5,7L / 7,6L / 9,5L	5,7L / 7,6L	5,7L / 7,6L	5,7L / 7,6L	7,6L	5,6L	6,2L
Multicooker programma's									
Pressure cooking	✓	✓	✓	✓	✓	✓	✓	✓	✓
Slow cooking	✓	✓	✓	✓	✓	✓	✓	✓	✓
Stomen	✓	✓	✓	✓	✓	✓	✓	✓	✓
Sauteren (aanbakken)	✓	✓	✓	✓	✓	✓	✓	✓	✓
Rijst/Graan	✓	✓	✓	✓	✓	✓	✓	✓	✓
Sous vide		✓		✓	✓	✓	✓	✓	✓
Yoghurt	✓	✓	✓	✓	✓	✓	✓	✓	✓
Bakken					✓	✓	✓		✓
Vlees/Stoofpot	✓	✓	✓	✓	✓	✓	✓	✓	✓
Bonen/Chili	✓	✓	✓	✓	✓	✓	✓	✓	✓
Inpotten (wecken)								✓	
Soep/Bouillon	✓	✓	✓	✓	✓	✓	✓	✓	✓
Rijst	✓	✓	✓	✓	✓	✓	✓	✓	✓
Bonen/Graan	✓	✓	✓	✓	✓	✓	✓	✓	✓
Pap/Havermout	✓	✓	✓	✓	✓	✓	✓	✓	✓
Pap	✓	✓	✓	✓	✓	✓	✓	✓	✓
Bonen	✓	✓	✓	✓	✓	✓	✓	✓	✓
Cake		✓		✓					
Airfryer programma's									
Air fry					✓		✓		✓
Braden					✓		✓		✓
Grillen					✓		✓		✓
Uitdrogen					✓		✓		✓
Rijzen				✓					✓
Soorten standen									
48 Programmeerbare pre-sets*				✓					
Druk niveau	✓		✓			✓	✓	✓	
Voorverwarmen		✓		✓		✓	✓	✓	✓
Temperatuur		✓	✓		✓	✓		✓	✓
Vertraging/Minuten									
Herinneren						✓			
Tijd	✓	✓	✓	✓	✓	✓	✓	✓	✓
Favoriet 1/2/3/4/5						✓			
Vertraging/Start	✓	✓	✓	✓	✓	✓	✓	✓	✓
Ventilator stand			✓						
Nutriboost aan/uit								✓	
Pressure cooking	✓	✓	✓	✓	✓	✓	✓	✓	✓
Kopen via Bol.com	Klik hier	Klik hier	Klik hier	Klik hier	Klik hier	Klik hier	Klik hier	Klik hier	Klik hier
Kopen via Amazon.nl	Klik hier	Klik hier	Klik hier	Klik hier	Klik hier	Klik hier	Klik hier	Klik hier	Klik hier

Legenda:

✓	Pre-set programma	✓	Zelf instellen
---	-------------------	---	----------------

[Klik hier voor de multicooker koopgids voor alle tips!](#)